




Illustrated Parts List

Portable Generator
Model 01924



Troy-Bilt® is a registered trademark of MTD and is used under license to Briggs & Stratton Power Products.

Troy-Bilt® es una marca registrada de MTD y se usa abajo licencia a Briggs & Stratton Power Products.

BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC
JEFFERSON, WISCONSIN, U.S.A.

Section 1: Exploded Views and Parts Lists

PARTS LIST - MAIN UNIT

Item	Part #	Description
1	P194779GS	CRADLE
2	197564GS	KIT,Vibration Mount
4	186058AGS	HOUSING, Engine Adapter
5	NSP	ASSY,Alternator (see page 6)
6	194151GS	KIT, Hardware Mounting Adapter
7	*	PPHMS, M8 1.25 x 40
8	96796GS	WASHER
9	67989GS	NUT, M8 Flange Serrated
10	*	HHCS, 5/16-24 x 3/4, SEMS
11	24823GS	HHCS, 5/16-24 x 7-7/8" Lg
13	*	HHCS, M6 1.0 x 12
14	191785GS	BRACKET, Muffler
15	697815	GASKET, Exhaust
17	188301GS	MUFFLER
18	*	SHCS, M6 - 1.0 x 20
19	83083GS	SCREEN, Spark Arrest
20	B4986GS	DECAL, Ground
21	194153GS	KIT,Vibration Mount
22	86494GS	SCREW,Wing M6 - 1.0 x 16
23	86292GS	SCREW, 10-16 x 3/4, Self Drill
24	191790GS	SHIELD, Heat
25	191190GS	CAP
26	74908GS	TAPTITE, M5-0.8 x 10 Lg.
31	191436GS	DECAL, Caution Hot Muffler
34	195422GS	COVER, Rear Bearing Carrier (Includes Item 25)
35	195207GS	KIT, Fuel Hose w/ Clips
37	B2153GS	HHCS, 12 - 14 x 7/8" Self Driller
40	194398GS	KIT, Fuel Tank Hardware
41	192980GS	KIT,Valve,Tank Fuel Service
44	193645GS	ASSY,Tank, Fuel (Includes Items 41, 50, 51 & 52)
45	B4363GS	GAUGE, Fuel
48	195373GS	WIRE, Ground
50	188333GS	DECAL, Fuel Level
51	194799GS	DECAL, Danger
52	189235GS	DECAL, Operating Instructions
55	191435GS	DECAL, Fuel Shut Off
58	191743AGS	ASSY, Control Panel (see page 4)
59	*	NUT, Palnut
900	§	ENGINE

Parts Not Illustrated


193354GS	MANUAL, Owners
43483GS	PLUG, 250V, 20A
MS5242	MANUAL, Engine
BB3061GS	BOTTLE OIL
193644GS	KIT, Decals Service

* - Items shown without part numbers are common fasteners found at your local hardware store.

§ - Contact Engine Manufacturer

Section 1: Exploded Views and Parts Lists

AC CONTROL PANEL EXPLODED VIEW & PARTS LIST




Item	Part #	Description
1	195112GS	KIT, Cover Control Panel
2	188889AGS	CONTROL PANEL, Compact
6	68759GS	OUTLET, 120V, 20Amp, Duplex
7	*	NUT, Palnut, Pushnut, 5/32
8	84198GS	CAP, Circuit Breaker
9	75207DGS	BREAKER, Circuit
10	68867GS	OUTLET, 120/240V Locking, 20A
11	*	NUT, Palnut, Pushnut, 3/16
12	*	PPPHS, M3 - 0.5 x 18
13	93857GS	BAR, Retaining
14	188890GS	COVER, Back, Control Panel
15	*	SCREW, 3 x 18, Tapping
16	22694GS	HOUSING, Receptacle
17	*	SCREW, 3.5 x 14, Tapping

* - Items shown without part numbers are common fasteners found at your local hardware store.

Section 1: Exploded Views and Parts Lists

WHEEL KIT EXPLODED VIEW AND PARTS LIST




Item	Part #	Description
1	189715GS	ASSY, Handle
2	B1764GS	LEG, Mounting
3	52858GS	NUT, Locking Hex M8 - 1.25
4	*	HHCS, M8 - 1.25 x 45
5	191267NGS	AXLE
6	B4966GS	WHEEL, 10" Diameter
7	191265GS	E-RING
8	*	WASHER, Flat
9	*	HHCS, M8 - 1.25 x 16

* - Items shown without part numbers are common fasteners found at your local hardware store.

Section 1: Exploded Views and Parts Lists

ALTERNATOR EXPLODED VIEW AND PARTS LIST



Item	Part #	Description
1	186059GS	ADAPTER, Mounting, Alternator
2	191685GS	ROTOR
3	191686AGS	STATOR
4	186060GS	RBC, with O-Ring (p/n 189197GS)
5	86308GS	SCREW
6	91825GS	ASSY, Holder, Rectifier/Brush
7	66849GS	SCREW
8	22694GS	RECEPTACLE, 6 pin
9	81917GS	PIN, Roll
10	193428AGS	ASSY, Wire, Ground
13	194274GS	HARNESS, Wire, Power